

# ProNature Wood Cleaner

The gentle giant of cleaners.

Product code: PN128

## Technical Data Sheet

### Product Description:

ProNature Wood Cleaner is the perfect, all-natural, non-toxic, biodegradable solution for keeping your wood surfaces looking their best. It's gentle enough to use every day, yet also powerful to remove dirt, grime and grease without drying out the wood. ProNature Wood Cleaner is safe to use on all types of wood surfaces including wood kitchenware.

### Ingredients:

Water, Potassium soaps

### Surface Preparation:

Clean surface of loose dirt. Scrub with a stiff bristle brush to remove intense dirt such as algae etc.

### Application:

Product is ready to use. Do not dilute.

- ✓ Moisten wood.
- ✓ Apply **ProNature Wood Cleaner** with a sponge or cloth.
- ✓ Allow product to soak into wood for 2-3 minutes.
- ✓ Use stiff short-bristle brush or scrubbing pad if necessary.
- ✓ Rinse with clean water.
- ✓ Extremely dirty or weathered wood may require a second treatment until wood shows its natural colour and grain.

### Storage/Shelf life:

Store in a cool and frost-free place.  
Minimum stability 24 month in closed container.

### Package Sizes:

500ml, 1l, 5l

### Safety:

Natural ingredients may cause allergies. Use only as directed. Store out of reach of children. Supervise children during use.

### General:

The above information given is intended as a guideline only. Since this product is used outside of our control, ProNature cannot be held liable for any loss or damage whatsoever relating to the application or surface it is applied to. We reserve the right to change specifications at any time and without prior notice.

